


Trimbre Linear Suspension

700LSTMB_

1.1



GENERAL PRODUCT INFORMATION:

This product is suitable for damp locations.

These fixtures are intended to be installed utilizing NEC compliant junction boxes.


This product can be dimmed with most ELV or TRIAC dimmers.

This instruction shows a typical installation.




CAUTION - RISK OF FIRE
 This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
 Use minimum 90°C supply conductors.


Install the Mounting Plate




1 Separate the mounting plate from the canopy by removing all four mounting plate screws with a screw driver.




2 Remove the mounting plate from the canopy.



3 Secure the mounting plate to the electrical box with the two #8-32 screws provided.


ID

- 4** Line up an anchor with the center of a backplate hole and push the anchor in, up to the threads.
- 5** Screw the anchor the rest of the way in with a screwdriver.


IE

- 6** Secure the backplate to the anchors with screws and washers.


Shorten the Cords (optional)

2A

- 1** Place the fixture on a level surface.
- 2** With the provided Allen wrench, loosen (do not remove) the set screws on the strain reliefs.
- 3** Evenly pull the cords up through the strain reliefs to raise the fixture to the desired height.
- 4** Ensure that the canopy is level and re-tighten the set screws on the strain reliefs.

2B


- 5** If shortening of the cords is necessary, take note of the wire connections from the fixture cords to the driver and remove the wire nuts.

2C


- 6** Leave 6" behind for wire connections, cut off the excess cord.
- 7** From the end of the cord, strip the insulation 4" using a sharp knife. **Make sure not to nick the inner wires.**
- 8** Strip the ends of the wires and reconnect the wires to their original connections using the wire nuts.

Install the Fixture

NOTE: It is recommended that one person hold the fixture while the electrician connects the power and installs the canopy.




- 1** Connect the fixture to a suitable ground in accordance with local electrical codes.
- 2** Connect the white driver wires to the neutral power line wire with a wire nut.
- 3** Connect the black driver wires to the hot power line wire with a wire nut.



- 4** Place all wires and wire nut connections inside the canopy.
- 5** Align the canopy holes with the mounting plate holes. Secure the canopy in place by tightening the four fixture screws.

Fine Leveling (Optional)


NOTE: If minor adjustments to the fixtures leveling is necessary, it is recommended that one person hold the fixture straight with the use of a level while the other adjusts the coaxial cable following the steps below.



- 1** Using the provided Allen wrench, loosen (do not remove) the set screws on the needed strain relief.
- 2** Gently pull or push the cable in very small increments through the strain relief to adjust the height of the fixture.
- 3** Re-tighten the set screw on the strain relief.

Adjust the Arms

5A



- I** The two lower arms (**not upper arm**) may be adjusted. To achieve this, loosen (**do not remove**) the set screw on both ends of the respective arm using the provided Allen wrench, adjust the arm to the desired position, and re-tighten the set screws to secure in place.

SAVE THESE INSTRUCTIONS!



TECH LIGHTING®

7400 Linder Ave, Skokie, IL 60077

847.410.4400

www.techlighting.com

© 2018 Tech Lighting, L.L.C. All rights reserved. The "Tech Lighting" graphic is a registered trademark of Tech Lighting, L.L.C. Tech Lighting reserves the right to change specifications for product improvements without notification.

A Generation Brands Company